READER COFIGURATION GUIDE 1-DOOR CONTROLLER (TS-WU-1DR)



CARD READER DATA CONFIGURATION DIFFERENCES

- Access control card readers can output data two ways, called "Card Read Order":
 - (1) MSB Most Significant Bit First
 - (2) LSB Least Significant Bit First
- TrueSecure 1-Door controllers can be configured to accept either Card Read Data output.
 (Default configuration is MSB Most Significant Bit First.) If your reader requires "LSB Least Significant Bit First" Card Read Data output, follow instruction below to make changes.
- Common reader Card Read Order output:

Card Reader	Card Read Order
TrueSecure TS-RU20-PB (SR3)	Most Significant Bit
TrueSecure TS-RU20-MB (SR4)	Most Significant Bit
WaveLynx Ethos	Most Significant Bit
Farpointe Pyramid	Most Significant Bit
HID Signo	Least Significant Bit
Farpointe Conekt	Least Significant Bit






1. OPEN APP AND SELECT 1-DR CONTROLLER

- Open the TrueSecure ADMIN app, and login to your account
- Select the 1-Door Controller from the Home page



2. CHANGE SETTING

- On the Device Page, Select "Settings" in the lower right
- Select "Advanced"
- Select "Card Read Order"
- Select the correct Card Read Order for your installed reader
- Select "Submit"



For more information visit: TrueSecurePro.com